
Add MidFDM to Cura



Start GCode


G28 ;Home G1 Z15.0 F6000 ;Move the platform down 15mm ;Prime the extruder G92 E0 G1 F150 E5 G92 E0

End GCode


M104 S0 M140 S0 ;Retract the filament G92 E1 G1 E-1 F300 G28 X0 Y0 M84

Z Offset Plugin Installation for Cura


- 1. Make sure you are connected to internet
- 2. Open Cura and open the marketplace



3. In the marketplace scroll down until you find the "Z Offset Setting" plugin and click on it



4. Click on install to install the plug5.



- 5. Close and reopen Cura
- 6. Find the "Z Offset" setting clicking on the MidFDM settings profile on the top right and typing "Z Offset" into the search bar
- 7. Adjust the "Z Off setting as needed"

